COFFEE PRESS

Directions for use:

- 1. Remove the filter assembly from the beaker.
- 2. Add one rounded tablespoon of ground coffee for each cup of coffee you wish to make. Do not use finely ground coffee because it might clog the filter.
- 3. Pour almost boiling water into the beaker being careful to keep the water level at least one inch (2.5 cm) from the top of the beaker. Stir lightly.
- 4. Place the lid onto the beaker with filter assembly fully raised.
- 5. Allow to brew for 3 to 5 minutes depending on your personal taste for weaker or stronger coffee.
- 6. To stop infusion, slowly lower filter assembly to bottom of beaker.
- 7. Your coffee is ready. Enjoy!

Directions for care:

- 1. Remove coffee and filter assembly from coffee maker.
- 2. Disassemble filter group.
- 3. Wash all components in warm soapy water, rinse thoroughly and then dry with a soft towel.
- 4. Reassemble filter group.

5 YEAR LIMITED WARRANTY

- Stainless steel spring plate



- Thin mesh stainless steel filter



- Stainless steel lower plate

CAFETIÈRE À PISTON

Mode d’emploi :

- 1. Retirer l’assemblage du filtre de la cafetière.
- 2. Ajouter une cuillère à table comble de café moulu pour chaque tasse de café que vous désirez faire. Ne pas utiliser de café à mouture fine puisqu’il peut boucher le filtre.
- 3. Verser de l’eau chaude au seuil de l’ébullition en prenant soin de laisser le niveau de l’eau à au moins 2,5 cm (1 pouce) du rebord. Mélanger doucement.
- 4. Replacer le couvercle avec l’assemblage du filtre complètement relevé.
- 5. Laisser infuser de 3 à 5 minutes selon votre goût pour un café plus ou moins fort.
- 6. Appuyez lentement sur la poignée de l’assemblage du filtre pour arrêter l’infusion.
- 7. Votre café est prêt à être dégusté !

Conseils d’entretien :

- 1. Retirer le couvercle et l’assemblage du filtre de la cafetière.
- 2. Démonter l’assemblage du filtre en le dévissant.
- 3. Laver toutes les pièces dans de l’eau tiède savonneuse, rincer et sécher avec un linge doux.
- 4. Refaire l’assemblage du filtre en revissant le tout.

- Plateau à ressort en inox

- Filtre de mèche fine en inox

- Plateau inférieur en inox